



Rocker switch and rocker button insert 10 AX 250 V~ 2-way switch / 2-way button



Specification	Order No.	Packing unit	PS	EAN
 2-way sw./2-way m-c	0139 00	1/5	01	4010337022725

Features

- Rocker switch and button in which the left rocker is laid out as a switch and the right rocker is laid out as a push button.
- For switching and colour control of an LED orientation light.
- For controlling motion detectors manually.
- For controlling dimmer auxiliary units.
- For controlling switched lighting.

Technical data

Installation depth:	32 mm
Connections - for conductors up to:	2.5 mm ²