







## Cover with toggle switch for time switch and blind switch/button



Specification	Order No.	Packing unit	PS	EAN
 cream white glossy	0666 01	5	01	4010337666011
 Pure white glossy	0666 03	5	01	4010337666035
 Pure white matt	0666 27	5	01	4010337666271
 Anthracite	0666 28	5	11	4010337666288
 Colour aluminium	0666 26	5	11	4010337666264
 Black matt	0666 005	5	11	4010337036586
 Grey matt	0666 015	5	11	4010337081401

### Notes

- This cover plate can be used universally by replacing the accompanying symbol plates for blind and time.

## Scope of supply

- Symbol plates for blinds ( , ) and time (15 to 120 min or 30 to 60 min) are included in the scope of supply.

---